

kontuur air

User Guide



Benel

www.benel.com.sg

kontuur air

Your ideal contour for maximum comfort.



www.benel.com.sg

Fixed Headrest

Specially designed to provide sufficient head and neck support while you are in a reclined position.




Adjustable Backrest

With both hands, move backrest up one step at a time. To lower, reset it by moving it up to its maximum height. Repeat steps to reach desired height.



3D Adjustable Armrests

Lift armrest button to adjust height of armrest. To position arm pads, grasp arm pad and push forward or backward, in or out.



Adjustable Seat Depth

While seated, push and hold lever on the left of the seat. Slide seat forward or backward, release to fix position.




Backrest Lock

On the left, turn knob in any direction to lock backrest at desired angle. To unlock, turn knob and lean back into the chair.



Tilt Tension

On the right, pull lever outwards to adjust. Turn clockwise to increase tilt tension. Turn anti-clockwise to reduce.



Adjustable Seat Height

On the right, lift lever to adjust seat height. Stay seated to lower height. Take weight off to raise seat height.

